



Güralp Data Centre

Operator manual

Contents


Acquisition software components diagram	3
Overview	4
Software components.....	4
Operating system.....	4
Requirements.....	4
Security	5
Configuration	5
IRIS ringserver	5
Ringserver miniSEED files storage location configuration	5
Ringserver miniSEED files storage auto-clean configuration.....	6
slinktool.....	6
slink2dali	7
Güralp Data Centre controller service	13
Güralp Data Centre monitor service	13
Güralp responder service.....	15
Güralp Discovery application	15
Operation.....	16
IRIS ringserver	16
slinktool.....	18
slink2dali	18
Güralp Data Centre controller service	18
Güralp Data Centre monitor service	19
Güralp responder service.....	19
Güralp Discovery application	20
State of Health	20
Configuration	28
Support	30
Version	30
Appendix 1 - Architecture	31
Overview	33



Software components.....	33
IRIS ringserver	33
slinktool.....	33
Güralp Data Centre controller service	33
Güralp Data Centre Monitor	33
Güralp responder service.....	35
Communication overview	35
Data Collection.....	35
Data Distribution.....	36
Configuration management.....	37
State of health.....	38
Summary	39
Network protocols and ports.....	39
Appendix 2 - Installation	40
Installation guide	41
Introduction	41
Operating system requirements.....	41
Software package content	41
Installation	41
Install libmseed	41
Install slinktool	42
Install slink2dali.....	42
Install Güralp Data Centre software	42
Verification.....	42
Download.....	43
Documentation:	43
Software packages:	43
Support	43



Acquisition software components diagram





Overview

Güralp Systems Data Centre software package (Acquisition software package) consists of several applications providing system state of health monitoring, data collection and distribution, and remote configuration capabilities. This document describes how to use and configure selected components of the software package.

Software components

List of all applications present in the software components diagram:

- IRIS ringserver
- slinktool
- slink2dali
- Güralp Data Centre controller service
- Güralp Data Centre monitor service
- Güralp responder service
- Güralp Discovery application

Optional components:

- Earthworm client
- SeiscomP3 client

Operating system

Requirements

Güralp Systems Data Centre software package has been tested on the following x86_64 platforms:

- Red Hat Enterprise Linux 8 (or equivalent, e.g. Rocky Linux 8 or AlmaLinux 8)
- Amazon Linux 2

Support for other platforms might be considered upon request (minimum system dependency requirements are: systemd v239, Qt v5.12.5, polkit v0.115).



Security

Güralp Systems Data Centre software requires access to the network in order to operate correctly. Please make sure that the system security settings allow the network traffic to and from the machine on ports specified in the table below. It also might be needed to configure SELinux features in relation to the mentioned requirements.

Port	Protocol	Description
11788	UDP	Used for sending and requesting state of health information by system components and Discovery desktop application.
11788	TCP	Configuration exchange protocol used by Discovery desktop application to configure data streaming connections.
16000	TCP	DataLink data transmission protocol connection to IRIS ringserver.
18000	TCP	SeedLink data transmission protocol connection to IRIS ringserver for both incoming and outgoing data streams.

Configuration

Ringserver

IRIS ringserver does not require any specific configuration unless change in either default storage location (`/var/cache/guralp/miniseed/`) or time for which the data is kept on the hard drive is required. Application runs as an operating system service and listens for SeedLink connections on TCP port 18000. If required listening port is different to 18000 please contact support@guralp.com for instructions.

Ringserver miniSEED files storage location configuration

IRIS ringserver storage location is configured by the home directory of ringserver user and if required can be changed by system administrator by editing the user properties. Newly selected directory should have sufficient permission and ownership. The steps below show how to modify the home directory of the ringserver user in Red Hat linux environment (please note that commands may require elevated permissions).

1. Copy `tmpfiles.d/guralp-miniseed.conf` file to `/etc` system location

```
cp /usr/lib/tmpfiles.d/guralp-miniseed.conf /etc/tmpfiles.d/guralp-miniseed.conf
```

2. Edit the copied configuration file and append a new line specifying the new storage location:

```
d /run/guralp/etc 0755 root root
F /run/guralp/etc/iris-ringserver.conf 0640 root ringserver - MSeedWrite %n_%s_%l_%c_%Y_%j.mseed
d /var/cache/guralp/miniseed 0775 root ringserver 3d
d /mnt/new/storage/directory 0775 root ringserver 3d
```

3. Save the changes made to the file



4. Modify the ringserver user home directory

```
usermod -d /mnt/new/storage/directory ringserver
```
5. Reboot the system to apply the changes

Please note that only the following top directories can be used: /home /media /mnt /opt /srv /var

Ringserver miniSEED files storage auto-clean configuration

IRIS ringserver storage is controlled by system tmpfiles clean timer and can be configured by editing guralp-miniseed.conf file. In order to change the configuration of time that historical data is kept in the system please follow the steps below.

1. Copy tmpfiles.d guralp-miniseed.conf file to /etc system location

```
cp /usr/lib/tmpfiles.d/guralp-miniseed.conf /etc/tmpfiles.d/guralp-miniseed.conf
```
2. Edit the copied configuration file and change the age of storage location to the required value.

d	/run/guralp/etc	0755	root	root	
F	/run/guralp/etc/iris-ringserver.conf	0640	root	ringserver	- MSeedWrite %n_%s_%l_%c_%Y_%j.mseed
d	/var/cache/guralp/miniseed	0775	root	ringserver	3d

where **3d** is the age of temporary files (read more: <https://www.freedesktop.org/software/systemd/man/tmpfiles.d.html>).
3. Save and reboot the system

slinktool

Slinktool process runs as a service with parameters provided through the service name in a form of a '@' separated list of values. Under normal operation there is no requirement to manually configure (enable/disable or start/stop) the service, this task is performed by the Data Centre controller on remote request from the Discovery desktop application.

Manual service configuration can be performed but it is not recommended. In order to do that, please log in to the Data Centre computer and use systemctl command to enable/disable and/or start/stop the slinktool service. Slinktool service is run with a set of parameters:

```
slinktool@NC@STATC@LOCHN@CONNECTION@PORT.service
```

where:

- NC, is SEED network code,
- STATC, is SEED station code,
- LOCHN, is SEED location and channel codes
- CONNECTION, is the connection IP address or hostname, for latency monitoring in the Data Centre this is set to 127.0.0.1 (localhost)
- PORT, is the connection port



Wildcard character for SEED location and channel name can be used and is represented by '_' character. Also, a list of location and channel names can be provided to a given service and should be separated with '-' character.

Example:

slinktool@DG@0585A@____@127.0.0.1@18000.service, will connect to station 0585A of DG network, subscribing to any channel (wildcard selector of 5x '_' character).


slinktool@DG@0585A@0NHHZ-0NHHN-0NHHE@127.0.0.1@18000.service, will connect to station 0585A of DG network, subscribing to 0N.HHZ, 0N.HHN and 0N.HHE channels.

slink2dali

Slink2dali process runs as a service with parameters provided through the service name in a form of a '@' separated list of values. Under normal operation there is no requirement to manually configure (enable/disable or start/stop) the service, this task is performed by the Data Centre controller on remote request from the Discovery desktop application.

In order to configure the required connection (slink2dali and slinktool services) use the Discovery desktop application.

1. Open Discovery desktop application and change the view to "Registry" mode
2. Right click on the Data Centre instance



3. Select Configuration option



4. In the configuration widget, if not preloaded with configuration, click on “Restore” button to retrieve the Data Centre configuration.

Oregon - Data Centre Configuration - Discovery

General settings

Registry group identifier: guralp3

Monitoring period for latency channels: 30

Monitoring period for active channels: 60

Monitoring period for active devices: 120

Filter for active channels monitoring: ?? ????? ?? ???

Filter for channels latency monitoring: ?? ????? .0N ???

Storage information base location

Registry servers

127.0.0.1 Remove Add server

Station subscription list

DG.06855 (81.149.31.241:18000) ?? ??? Remove

Add station from discovered Add station manually

Restore Cancel Apply

5. Widget populates the list of currently configured connections and provides control button to remove the connection if no longer required. Connection subscription channel list can contain multiple SEED channel names (LOCATION_CODE.CHANNEL_CODE) defined as a space (' ')



separated list.

oregon - Data Centre Configuration - Discovery

General settings

Registry group identifier:

Monitoring period for latency channels:

Monitoring period for active channels:

Monitoring period for active devices:

Filter for active channels monitoring:

Filter for channels latency monitoring:

Storage information base location:

Registry servers


Station subscription list

DG.06855 (81.149.31.241:18000)	<input type="text" value="?.???"/>	<input type="button" value="Remove"/>
--------------------------------	------------------------------------	---------------------------------------



6. Connections can be quickly added from the list of stations populated in the Discovery desktop application main window through “Add station from discovered” button, or manually by clicking on “Add station manually”.
 - a. Add station from discovered.

When actioned, new widget with a list of discovered stations is displayed and tick-boxes are available for selecting to which stations the Data Centre should connect to. Once list contains required stations, press “Add selected” button to confirm.



- b. Add station manually

To add device that is not supporting Güralp Discovery mechanism, please press on “Add station manually” button which populates a simple widget asking for details required to create the connection from the Data Centre to the device.

Required fields:

- SEED Network code
- SEED Station code
- Connection IP address



To confirm, click on “Add station” button.

Monitoring period for active channels: 00

Monitoring period for active devices: 120

Filter for active channels monitoring: ??,?????,??,???

Filter for channels latency monitoring: ??,?????,??,???

Station details dialog box:

- Station information as SEED_NETWORK SEED_STATION (eg. DG 01234):
- Connection IPv4 address:
- Buttons: Cancel, Add station

D.9059	??,???	Remove
DG.0585A	??,???	Remove
DG.07957	??,???	Remove
DG.12345	01,???,?N,???	Remove

Buttons: Add station from discovered, Add station manually



7. When all connections are added to the list, click “Apply” button to send the updated configuration to the Data Centre. Data Centre controller service will enable and start all required slinktool and slink2dali services. If station was removed from the list, the controller service will stop and disable the services used to connect to the removed device.

Note: Other configuration fields are explained in the [Discovery application configuration section](#) of this document.

Manual service configuration can be performed but it is not recommended. In order to manually configure a connection, please log in to the Data Centre computer and use systemctl command to enable/disable and/or start/stop the slink2dali service. Slink2dali service is run with a set of parameters:

```
slink2dali@NC@STATC@LOCHN@CONNECTION@PORT@STATEFILES@SAVEINTERVAL.service
```

where:

- NC, is SEED network code,
- STATC, is SEED station code,
- LOCHN, is SEED location and channel codes
- CONNECTION, is the connection IP address or hostname
- PORT, is the connection port



- STATEFILESAVEINTERVAL, defines interval for state file save (can be blank)

Wildcard character for SEED location and channel name can be used and is represented by '_' character. Also, a list of location and channel names can be provided to a given service and should be separated with '-' character.

Example:

slink2dali@DG@0585A@_____@10.30.0.123@18000.service, will connect to station 0585A of DG network using IP address 10.30.0.123 and port 18000 subscribing to any channel (wildcard selector of 5x '_' character).

slink2dali@DG@0585A@0NHHZ-0NHHN-0NHHE@10.30.0.123@18000.service, will connect to station 0585A of DG network using IP address 10.30.0.123 and port 18000 subscribing to 0N.HHZ, 0N.HHN and 0N.HHE channels.

Güralp Data Centre controller service

Güralp Data Centre controller does not require any specific configuration. Application runs as a service and does not need particular maintenance.

Güralp Data Centre monitor service

Güralp Data Centre Monitor service should be configured remotely by accessing Configuration widget in the Discovery application. The configuration widget is available under right-click menu of a Data Centre row.

Status	Label	System	Name	Serial#	Firmware Ver	WAN Address	LAN Address	Netmask	Uptime	Latitude	Longitude	Altitude	Free storage	Network latency	Data latency
⚠	Comet FEM_TEST_JIG	Aquarius	AQU-145A	5210	2.1-10023	10.30.0.18	10.30.0.18	255.255.0.0	00:00:24	0.0000	0.0000	-12.34		n/a	n/a
✅	Comet Test Rack	Fortimus	FMUS-585A	22618	2.1-11215	10.30.0.68	10.30.0.68	255.255.0.0	26 days 22 Hrs	51.3612	-1.1643	125.00	70.99%	n/a	n/a
✅	Comet R&D	Fortimus	FMUS-9059	36953	2.1-11311	10.30.0.20	10.30.0.20	255.255.0.0	4 days 0 Hrs	51.3614	-1.1639	-12.34	98.68%	n/a	n/a
✅	Comet Five-character serial number	Minimus	MIN-12345	74565	2.1-11547	10.30.0.11	10.30.0.11	255.255.0.0	6 days 23 Hrs	51.3612	-1.1640	114.20	97.73%	3.90s	4.53s
✅	Comet NO LABEL	Minimus	MIN-7957	31063	2.1-11312	10.30.0.49	10.30.0.49	255.255.0.0	00:36:21	51.3615	-1.1640	-12.34	99.85%	n/a	n/a
✅	Comet NO LABEL	Minimus	MIN-9355	37717	2.0-8282	10.30.0.90	10.30.0.90	255.255.0.0	10 days 23 Hrs	-59.9000	85.5410	-12.34	4.87%	n/a	n/a
⚠	Comet Orac	Minimus	MIN-CC57	52311	2.1-1679	10.30.0.38	10.30.0.38	255.255.0.0	00:00:46	51.3612	-1.1640	-12.34	99.23%	n/a	n/a
✅	Comet deck@agu-deck-dev.guralp.local	Discovery	agu-deck-dev	4C5262264CEC	1.1-263	10.30.0.108	10.30.0.108	255.255.0.0	6 days 0 Hrs	51.3611	-1.1639	0.00	97.94%	n/a	n/a
✅	Comet DATC@guralp.guralp.local	guralp	guralp	0B850E68E7E9e	0.3-1	10.30.0.37	10.30.0.37	255.255.0.0	02:51:00	0.0000	0.0000	0.00	67.46%	3.90s	4.47s

Manual configuration can be performed but is not recommended. Configuration is stored in a configuration file located in /var/cache/guralp/guralp-monitor.ini and contains a set of key-value entries:

Key	Description	Type
-----	-------------	------



registry_addresses	Comma separated IP addresses of Güralp responder servers to which the state of health packet should be send to	Comma separated list of strings
registry_group_id	Güralp responder server group identifier string used. Please use "guralp3" as a default value	String
filter_monitored_channels	SEED globing style filter for channels activity monitoring	String
filter_monitored_latency_channels	SEED globing style filter for channels latency monitoring	String
monitoring_period_latency	Period of time in seconds that should be used to find the highest data latency	Integer
monitoring_period_active_channels	Period of time in seconds that should be used to detect number of active channels	Integer
monitoring_period_active_devices	Period of time in seconds that should be used to detect number of active devices	Integer
storage_monitor_dir	Directory that should be used for storage monitoring, if this entry is not present, iris ringserver working directory is used.	String

Example guralp-monitor.ini file content:

```
[Version_1]
filter_monitored_channels="^.{1,2}\\..{1,5}\\.\\.N\\.\\. {1,3}"
filter_monitored_latency_channels="^.{1,2}\\..{1,5}\\.\\.N\\.\\. {1,3}"
monitoring_period_active_channels=120
monitoring_period_active_devices=300
monitoring_period_latency=30
registry_addresses=127.0.0.1,
registry_group_id=guralp3
storage_monitor_dir=/var/cache/guralp/miniseed
```



Güralp responder service

Güralp responder service provides a configuration option for specifying a wildcard group identifier that grants access to all of the registered devices. Wildcard group identifier can be used in the Discovery desktop application to list all of the stations that are connected to the Data Centre even if they are registering with a different, non-matching, group identifiers.

Wildcard group identifier can be set by creating a configuration file under tmpfiles.d directory. The configuration file generates the content of /run/guralp/etc/wildcard_groupid.txt file that is read by the responder service on startup and the content is used as the wildcard. To configure a custom wildcard string please follow the steps below.

1. Copy tmpfiles.d configuration file to system location.

```
cp /usr/lib/tmpfiles.d/guralp-responder.conf /etc/tmpfiles.d/guralp-responder.conf
```
2. Edit the configuration file /etc/tmpfiles.d/guralp-responder.conf to generate the selected wildcard string.

Example content of /etc/tmpfiles.d/guralp-responder.conf

```
d /run/guralp/etc 0755 root root
F /run/guralp/etc/wildcard_groupid.txt 0640 root guralpmonitor - customWildcard
```

Where, **customWildcard** is the new wildcard string.

3. Save the modified file.
4. Restart the operating system.


Güralp Discovery application

Güralp Discovery desktop application when used for monitoring the state of health of the Data Centre has to be configured to use the Data Centre IP address as a Cloud registry server. Discovery supports multiple cloud registry endpoints and these are configured under File/Settings menu action, also accessible by clicking on the “Cloud server configuration” label of the application main window.





To add a cloud registry endpoint, please click on an “Add” button in the “Cloud registry” section and provide endpoint hostname or IP address. Please note that hostnames will get automatically translated to IP address and stored as IPv4 address.



When all of the Data Centre instances are added to the list, click on the “Apply” button to confirm the changes.

It is important to set the “Cloud registry group identifier” field to reflect the configuration of the Data Centre Monitor and the Güralp seismic stations (e.g. Minimus or Fortimus). Misconfiguring this setting will cause the list of active devices to be blank in the “Registry” mode of the Discovery application.

To reduce the amount of network traffic, the frequency of state of health information packet requests from the Cloud server can be configured by changing the “Cloud query interval” setting.

Operation

IRIS ringserver

IRIS ringserver service status is displayed in State of Health dashboard of the Data Centre instance and should be regularly monitored to assure correct operation of the software. The State of Health dashboard is available under right-click menu of the Data Centre row in the Discovery desktop application.



Güralp Systems - Discovery

File Edit Tools Window Help


Status	Label	System	Name	Serial#	Firmware Ver	WAN Address	LAN Address	Netmask	Uptime	Latitude	Longitude	Altitude	Free storage	Network latency	Data latency
⚠	Comet FEM_TEST_JIG	Aquarius	AQU-145A	5210	2.1-10023	10.30.0.18	10.30.0.18	255.255.0.0	00:00:24	0.0000	0.0000	-12.34	n/a	n/a	
✅	Comet Test Rack	Fortimus	FMUS-585A	22618	2.1-11215	10.30.0.68	10.30.0.68	255.255.0.0	26 days 22 Hrs	51.3612	-1.1643	125.00	70.99%	n/a	n/a
✅	Comet R&D	Fortimus	FMUS-9059	36953	2.1-11311	10.30.0.20	10.30.0.20	255.255.0.0	4 days 0 Hrs	51.3614	-1.1639	-12.34	98.68%	n/a	n/a
✅	Comet Five-character serial number	Minimus	MIN-12345	74565	2.1-11547	10.30.0.11	10.30.0.11	255.255.0.0	6 days 23 Hrs	51.3612	-1.1640	114.20	97.73%	3.90s	4.53s
✅	Comet NO LABEL	Minimus	MIN-7957	31063	2.1-11312	10.30.0.49	10.30.0.49	255.255.0.0	00:36:21	51.3615	-1.1640	-12.34	99.85%	n/a	n/a
✅	Comet NO LABEL	Minimus	MIN-9355	37717	2.0-8282	10.30.0.90	10.30.0.90	255.255.0.0	10 days 23 Hrs	-59.9000	85.5410	-12.34	4.87%	n/a	n/a
⚠	Comet Orac	Minimus	MIN-CC57	52311	2.1-1679	10.30.0.38	10.30.0.38	255.255.0.0	00:00:46	51.3612	-1.1640	-12.34	99.23%	n/a	n/a
⚠	Comet deck@aqu-deck-dev.guralp.local	Discovery	aqu-deck-dev	4C5262264CEC	1.1-263	10.30.0.108	10.30.0.108	255.255.0.0	6 days 0 Hrs	51.3611	-1.1639	0.00	97.94%	n/a	n/a
✅	Comet DATC@guralp.guralp.local	Data Centre Health Dashboard	guralp	10.30.0.37	D890F68E7E9E10.3-1	10.30.0.37	10.30.0.37	255.255.0.0	02:51:00	0.0000	0.0000	0.00	67.46%	3.90s	4.47s

guralp 10.30.0.37
State of health dashboard
Configuration

Scan Locally Registry Cloud server configuration

Registered Systems Experimental mode

Bottom left part of the dashboard provides information about the state of services required for correct data centre operation. If for any reason service displayed as “iris-ringserver.service” is not listed as “active”, please log in to the Data Centre computer and investigate using systemctl tools. If problem persists, please contact Güralp support.





slinktool

Slinktool service is controlled by the Data Centre controller service and does not require operational maintenance. In a rare case when the reported latency seems not to be correct, it is recommended to login to the Data Centre computer and check the relevant slinktool service status using systemctl command.

slink2dali

Slink2dali service is controlled by the Data Centre controller service and does not require operational maintenance. In a rare case when the data is not received on the client side, it is recommended to login to the Data Centre computer and check the relevant slink2dali service status using systemctl command.

Slinktool and slink2dali services can be remotely restarted by removing and re-adding the seismic station to the list of connections in the Data Centre configuration widget.

Güralp Data Centre controller service

Güralp Data Centre controller service does not require regular maintenance. If the service is not responding or configuration exchange between the Discovery desktop application and the Data Centre is not working, please ssh log in to the Data Centre computer and check the status of guralp-controller service:

```
systemctl status guralp-controller.service
```

If status returned is different from active:

```
guralp-controller.service - Güralp data centre controller
Loaded: loaded (/usr/lib/systemd/system/guralp-controller.service; enabled; vendor preset: disabled)
Active: active (running) since Tue 2021-07-20 09:58:27 BST; 6min ago
Main PID: 1660 (guralp-controll)
Tasks: 1 (limit: 48584)
Memory: 12.2M
CGroup: /system.slice/guralp-controller.service
        1660 /usr/libexec/guralp-controller -exec
```

```
Jul 20 09:58:27 guralp systemd[1]: Started Güralp data centre controller.
Jul 20 09:58:30 guralp guralp-controller[1660]: Service initialised
Jul 20 09:58:30 guralp guralp-controller[1660]: Listening on port 11788
```

Restart the service using systemctl command:

```
systemctl restart guralp-controller.service
```

If problem persists, please contact Güralp Systems support team at support@guralp.com.



Güralp Data Centre monitor service

Güralp Data Centre monitor service sends periodic state of health information packet to all configured Responder servers and performs latency monitoring. If the Data Centre row in the Discovery desktop application is listed as non-responding it means that the application did not receive state of health information from the Data Centre for more than 90 seconds what may indicate that either the server is down, or the Data Centre monitor is not working, or Güralp responder service stopped working, or there is no connection between the Discovery application and the server. In such situation, please try to ssh log in to the server, and if successful check the status of the Data Centre service by running systemctl command:

```
systemctl status guralp-monitor.service
```

The service should be in active state:

```
guralp-monitor.service - Güralp data centre monitor
  Loaded: loaded (/usr/lib/systemd/system/guralp-monitor.service; enabled; vendor preset: disabled)
  Active: active (running) since Tue 2021-07-20 09:58:27 BST; 20min ago
  Main PID: 1659 (guralp-monitor)
  Tasks: 4 (limit: 48584)
  Memory: 21.2M
  CGroup: /system.slice/guralp-monitor.service
          1659 /usr/libexec/guralp-monitor -exec

Jul 20 09:58:27 guralp systemd[1]: Started Güralp data centre monitor.
```

If the service is not in an active state, please try to restart the service using systemctl command:

```
systemctl restart guralp-monitor.service
```

If problem persists, please contact Güralp Systems support team at support@guralp.com.

Güralp Data Centre monitor service periodically monitors the slinktool log files in order to gather accurate latency information and feed it to the Güralp responder service for further processing. The highest latency number detected in the configured latency monitoring window is set as Data Centre latency figure and is displayed in the Discovery desktop application. The service records all of the latency data information in a csv and log files stored under home directory of the “slinklat” operating system user, set by default to /var/cache/guralp/latency. Default configuration keeps the recorded data files for 10 days and older files are getting deleted through tmpfiles.d mechanism.

Güralp responder service

Güralp responder service is responsible for collecting and distributing state of health information from Güralp devices. Potential problems caused by malfunction in the service operation will cause the Discovery desktop application to display incorrect state of health information or the list of devices in the application main windows will be empty under the “Registry” mode. If the responder service is malfunctioning, please ssh log in to the Data Centre computer and verify the state of the service by executing the following systemctl command:



```
systemctl status guralp-responder.service
```

Service should be in active state:

```
guralp-responder.service - Güralp responder (a.k.a. Güralp registry server)
Loaded: loaded (/usr/lib/systemd/system/guralp-responder.service; enabled; vendor preset: disabled)
Active: active (running) since Tue 2021-07-20 11:06:17 BST; 7min ago
Main PID: 1639 (guralp-responde)
Tasks: 5 (limit: 48584)
Memory: 500.0K
CGroup: /system.slice/guralp-responder.service
        1639 /usr/libexec/guralp-responder -d
```

```
Jul 20 11:06:17 guralp guralp-responder[1639]: Discovery Server version 0.80-0091
Jul 20 11:06:17 guralp guralp-responder[1639]: Devices expire after one day
Jul 20 11:06:17 guralp guralp-responder[1639]: Opening pinger UDP listener, port 11788
Jul 20 11:06:17 guralp guralp-responder[1639]: Socket 4
```

If the service is not in an active state, please try to restart the service using systemctl command:


```
systemctl restart guralp-responder.service
```

If problem persists, please contact Güralp Systems support team at support@guralp.com.

Güralp Discovery application

Güralp Discovery is a standalone application dedicated to run in a desktop environment with Windows, Linux or Mac operating system. The application provides multiple functionalities for controlling, diagnosing and monitoring Güralp Systems devices and software products. For the Data Centre acquisition software solution, Discovery is used for configuration and monitoring the Data Centre server state of health.

State of Health





The graph above shows the state of health packet circulation in an environment with 2 local area networks and 1 Güralp responder server instance. The Data Centre software package includes Güralp responder service and the Data Centre acts as a server.

State of health information can be delivered to the Discovery application in 2 ways:

- In a local network, state of health information can be broadcasted by UDP packet sent on port 11788, Discovery is listening to the valid broadcast packets and lists the device in the applications main window table under “local” mode.
- State of health information can be sent directly to Güralp responder server where it is collected and distributed to the Discovery upon request. In “Registry” mode the application is querying the responder periodically for the latest information.

The Data Centre state of health can be monitored in the real time either in the Discovery desktop application main window by checking the status indication icons, and/or by accessing the dedicated Data Centre state of health widget.

Status	Label	System	Name	Serial#	Firmware Ver	WAN Address	LAN Address	Netmask	Uptime	Latitude	Longitude	Altitude	Free storage	Network latency	Data latency
🔴	Comet FEM_TEST_JIG	Aquarius	AQU-145A	5210	2.1-10023	10.30.0.18	10.30.0.18	255.255.0.0	00:00:24	0.0000	0.0000	-12.34	n/a	n/a	n/a
🟢	Comet Test Rack	Fortimus	FMUS-585A	22618	2.1-11215	10.30.0.68	10.30.0.68	255.255.0.0	26 days 22 Hrs	51.3612	-1.1643	115.80	70.99%	n/a	n/a
🟢	Comet R&D	Fortimus	FMUS-9059	36953	2.1-11311	10.30.0.20	10.30.0.20	255.255.0.0	4 days 0 Hrs	51.3614	-1.1639	-12.34	98.68%	n/a	n/a
🟢	Comet Five-character serial number	Minimus	MIN-12345	74565	2.1-11547	10.30.0.11	10.30.0.11	255.255.0.0	6 days 23 Hrs	51.3612	-1.1640	113.50	97.73%	3.90s	4.50s
🟢	Comet NO LABEL	Minimus	MIN-7957	31063	2.1-11312	10.30.0.49	10.30.0.49	255.255.0.0	00:35:51	51.3615	-1.1640	-12.34	99.85%	n/a	n/a
🟢	Comet NO LABEL	Minimus	MIN-9355	37717	2.0-8282	10.30.0.90	10.30.0.90	255.255.0.0	10 days 23 Hrs	-59.9000	85.5410	-12.34	4.87%	n/a	n/a
🔴	Comet Orac	Minimus	MIN-CC57	52311	2.1-1679	10.30.0.38	10.30.0.38	255.255.0.0	00:00:46	51.3612	-1.1640	-12.34	99.23%	n/a	n/a
🟢	Comet deck@aqu-deck-dev.guralp.local	Discovery	aqu-deck-dev	4CS262264CEC	1.1-263	10.30.0.108	10.30.0.108	255.255.0.0	6 days 0 Hrs	51.3611	-1.1639	0.00	97.94%	n/a	n/a
🔴	Comet DATC@guralp.guralp.local	Data Centre	guralp	D850F6BE7E56	0.3.1	10.30.0.37	10.30.0.37	255.255.0.0	02:50:30	0.0000	0.0000	0.00	67.46%	3.90s	4.50s

First status icon indicates the active state of the Data Centre. Active state traffic light colour scheme indicates the following:

- Green background – state of health information was received in last 30 seconds.
- Amber background – system is booting.
- Red background – state of health information was not received for more than 90 seconds.



Status	Label	System	Name	Serial#	Firmware Ver	WAN Address	LAN Address	Netmask	Uptime	Latitude	Longitude	Altitude	Free storage	Network latency	Data latency
	Comet FEM_TEST_JIG	Aquarius	AQU-145A	5210	2.1-10023	10.30.0.18	10.30.0.18	255.255.0.0	00:00:24	0.0000	0.0000	-12.34	n/a	n/a	n/a
	Comet Test Rack	Fortimus	FMUS-585A	22618	2.1-11215	10.30.0.68	10.30.0.68	255.255.0.0	26 days 22 Hrs	51.3612	-1.1643	115.80	70.99%	n/a	n/a
	Comet R&D	Fortimus	FMUS-9059	36953	2.1-11311	10.30.0.20	10.30.0.20	255.255.0.0	4 days 0 Hrs	51.3614	-1.1639	-12.34	98.68%	n/a	n/a
	Comet Five-character serial number	Minimus	MIN-12345	74565	2.1-11547	10.30.0.11	10.30.0.11	255.255.0.0	6 days 23 Hrs	51.3612	-1.1640	113.50	97.73%	3.90s	4.50s
	Comet NO LABEL	Minimus	MIN-7957	31063	2.1-11312	10.30.0.49	10.30.0.49	255.255.0.0	00:35:51	51.3615	-1.1640	-12.34	99.85%	n/a	n/a
	Comet NO LABEL	Minimus	MIN-9355	37717	2.0-8282	10.30.0.90	10.30.0.90	255.255.0.0	10 days 23 Hrs	-59.9000	85.5410	-12.34	4.87%	n/a	n/a
	Comet Orac	Minimus	MIN-CC57	52311	2.1-1679	10.30.0.38	10.30.0.38	255.255.0.0	00:00:46	51.3612	-1.1640	-12.34	99.23%	n/a	n/a
	Comet deck@aqu-deck-dev.guralp.local	Discovery	aqu-deck-dev	4C5262264CEC	1.1-263	10.30.0.108	10.30.0.108	255.255.0.0	6 days 0 Hrs	51.3611	-1.1639	0.00	97.94%	n/a	n/a
	Comet DATC@guralp.guralp.local	Data Centre	guralp	D850E68E7E96	0.3-1	10.30.0.37	10.30.0.37	255.255.0.0	02:50:30	0.0000	0.0000	0.00	67.46%	3.90s	4.50s

Second status icon indicates the latency status of the data coming in to the Data Centre. Data Centre monitors the latency of all channels received and satisfied by the latency channels monitoring filter and sends the highest latency in the state of health information packet. The latency status traffic light colour scheme indicates the following:

- Green background – the highest latency value is below 1 second.
- Amber background – the highest latency value is between 1 second and 1.5 second.
- Red background – the highest latency value is above 1.5 second.

Status	Label	System	Name	Serial#	Firmware Ver	WAN Address	LAN Address	Netmask	Uptime	Latitude	Longitude	Altitude	Free storage	Network latency	Data latency
	Comet FEM_TEST_JIG	Aquarius	AQU-145A	5210	2.1-10023	10.30.0.18	10.30.0.18	255.255.0.0	00:00:24	0.0000	0.0000	-12.34	n/a	n/a	n/a
	Comet Test Rack	Fortimus	FMUS-585A	22618	2.1-11215	10.30.0.68	10.30.0.68	255.255.0.0	26 days 22 Hrs	51.3612	-1.1643	115.80	70.99%	n/a	n/a
	Comet R&D	Fortimus	FMUS-9059	36953	2.1-11311	10.30.0.20	10.30.0.20	255.255.0.0	4 days 0 Hrs	51.3614	-1.1639	-12.34	98.68%	n/a	n/a
	Comet Five-character serial number	Minimus	MIN-12345	74565	2.1-11547	10.30.0.11	10.30.0.11	255.255.0.0	6 days 23 Hrs	51.3612	-1.1640	113.50	97.73%	3.90s	4.50s
	Comet NO LABEL	Minimus	MIN-7957	31063	2.1-11312	10.30.0.49	10.30.0.49	255.255.0.0	00:35:51	51.3615	-1.1640	-12.34	99.85%	n/a	n/a
	Comet NO LABEL	Minimus	MIN-9355	37717	2.0-8282	10.30.0.90	10.30.0.90	255.255.0.0	10 days 23 Hrs	-59.9000	85.5410	-12.34	4.87%	n/a	n/a
	Comet Orac	Minimus	MIN-CC57	52311	2.1-1679	10.30.0.38	10.30.0.38	255.255.0.0	00:00:46	51.3612	-1.1640	-12.34	99.23%	n/a	n/a
	Comet deck@aqu-deck-dev.guralp.local	Discovery	aqu-deck-dev	4C5262264CEC	1.1-263	10.30.0.108	10.30.0.108	255.255.0.0	6 days 0 Hrs	51.3611	-1.1639	0.00	97.94%	n/a	n/a
	Comet DATC@guralp.guralp.local	Data Centre	guralp	D850E68E7E96	0.3-1	10.30.0.37	10.30.0.37	255.255.0.0	02:50:30	0.0000	0.0000	0.00	67.46%	3.90s	4.50s


The last, third status icon shows the Data Centre storage status. The traffic light colour scheme for the Data Centre storage indicates the following:

- Green background - more than 50% of disk space is free.
- Amber background – between 20% and 50% of disk space is free.




- Red background – less than 20% of disk space is free.

More descriptive tooltip is provided when hovering over the status icons of a given device:




Data Centre state of health dashboard widget can be accessed through right-click menu of selected instance:



The state of health dashboard widget is divided into 4 main parts:




- Top-left widget is a latency graph displaying the highest historical latency value for up to last 30 minutes.






- Top-right widget is a disk usage graph displaying the disk free space in MB (blue graph, left y axis) and disk used space percentage (red graph, right y axis)






- Bottom-left widget displays the state of services running on the Data Centre and allows to configure the logfile and output data file for activity log and latency/disk usage data respectively





- Bottom-right widget displays the activity log based on state of health information packets received



Log line contains the following information:

- Timestamp
- Latency value
- Sample latency value
- Number of active channels
- Number of active devices
- Latest sample timestamp
- Available disk space in KB
- Disk used space in KB
- Percentage value of free disk space

And is logged as single line in the following format:

```
{[Timestamp]} Latency: {Latency value}s; Sample latency: {Sample latency value}s; Active channels: {Number of active channels}; Active devices: {Number of active devices}; Latest sample timestamp: {Latest sample timestamp}; Disk available: {Available disk space in KB}; Disk used: {Disk used space in KB}; Disk free: {Percentage value of free disk space}%;
```

Example:




[Fri Jul 9 13:50:34 2021] Latency: 1.50s; Sample latency: 1.81s; Active channels: 26; Active devices: 2; Latest sample timestamp: Fri Jul 9 13:49:43 2021; Disk available: 73364480; Disk used: 54698232; Disk free: 25.44%;

Configuration


Under normal operation tweaks to the health monitor configuration, list of connected devices or Güralp responder server connections might be required. For connecting or disconnecting from the stations please refer to [Configuration/Slink2dali](#) section of this document, and for modification of the Discovery desktop application responder server connection please refer to [Configuration/Güralp Discovery application](#) section.

Güralp Discovery application provides a configuration widget for the Data Centre accessible through right-click menu in the application main window.



The configuration widget is split in 3 parts:

- General settings, providing a set of text edit fields for Güralp Data Centre monitor:
 - o Registry group identifier – Group identifier used for registration to the Güralp responder server.
 - o Monitoring period for latency channels – Period of time in seconds that should be used for detecting the highest channel latency value.
 - o Monitoring period for active channels – Period of time in seconds that should be used for detecting the number of active channels.
 - o Monitoring period for active devices – Period of time in seconds that should be used for detecting the number of active devices.
 - o Filter for active channels monitoring – A SEED globing pattern defining the channels that are monitored for being active. Accepts a space (' ') separated list.
 - o Filter for channels latency monitoring – A SEED globing pattern defining the channels that are monitored for latency calculation. Accepts a space (' ') separated list.
 - o Storage information base location – Location that should be used for disk space information gathering. Leave blank for default (the service working directory).



Support

For support enquiries, please contact support@guralp.com.

Güralp Systems Limited
 Midas House, Calleva Park, Aldermaston,
 Reading, RG7 8EA,
 United Kingdom

Tel: +44 118 981 9056

Fax: +44 118 981 9943

E-mail: sales@guralp.com

Version

Version	Date	Author	Comment
1	2021/08/03	P Grabalski	Initial upload
2	2021/08/04	P Grabalski	Spelling corrections



3	2021/08/24	P Grabalski	Update of “Configuration/Güralp responder service” section to show latest configuration file content (pipe file configuration line added)
4	2021/10/04	P Grabalski	Screenshots update to reflect widgets from Discovery version 1.1-267
5	2021/11/01	P Grabalski	Screenshots update to contain default data centre group ID “guralp3”. Security sub-section added to operating system section to explain the networking requirements.

Appendix 1 - Architecture




Figure 1 GDC Architecture



Overview

Güralp Data Centre software consists of several applications providing system state of health monitoring, data collection and distribution, and remote configuration capabilities. This document describes the software packages provided, explaining the architecture, software components and communication between them.

Software components

List of all applications included in Data Centre software package:

- IRIS ringserver
- slinktool
- Güralp Data Centre controller service
- Güralp Data Centre monitor
- Güralp responder service

Ringserver

Ringserver is a well-established stream-oriented packet ring buffer used primarily to transport packetized time series of data. **Ringserver** supports TCP based protocols: **DataLink**, **SeedLink**, and **HTTP/WebSocket**. The program has a built-in **miniSEED** archiver and in default configuration provided by Güralp, keeps the data archived for last 3 days.

Configuration details can be found in Güralp Data Centre Operator Manual.

Read more: <https://github.com/iris-edu/ringserver>

slinktool

Slinktool is used as a diagnostic **SeedLink** client for latency monitoring. The tool connects to the **ringserver** and examines the latency of the data packets received. Latency is reported to the system log which is then read by Güralp Data Centre Monitor application and the highest latency value is sent in the state of health packet.

Read more: <https://github.com/iris-edu/slinktool>

Güralp Data Centre controller service

Güralp Data Centre controller service is a stand-alone application, run as a service, responsible for **SeedLink** connection management and Güralp Data Centre Monitor configuration. The application communicates with the Discovery desktop application through **TCP** connection on port **11788** using proprietary protocol in both directions: Discovery-service and service-Discovery.

Service is enabling/disabling and starting/stopping **slink2dali** and **slinktool** services responsible for data collection and latency calculation for each seismic station connected to data centre. Additionally, this service modifies the configuration of the Data Centre Monitor with settings configured by the Operator in a dedicated graphical user interface widget in the Discovery desktop application.

Güralp Data Centre Monitor

Güralp Data Centre Monitor service is a stand-alone application, run as a service, responsible for the periodic sending of state of health packets containing the latest information about Data Centre. State of health packets are sent to selected Güralp responder instances and can be configured by the Operator through either a dedicated GUI widget in Discovery desktop application, or by manually editing the **guralp-monitor.ini** configuration file.



The configuration file is located in `/var/cache/guralp/guralp-monitor.ini` and contains pairs of key-value entries:

Key	Description	Type
<code>registry_addresses</code>	Comma separated IP addresses of Güralp responder servers to which the state of health packet should be send to	Comma separated list of strings
<code>registry_group_id</code>	Güralp responder server group identifier string used	String
<code>filter_monitored_channels</code>	SEED globing style filter for channels activity monitoring	String
<code>filter_monitored_latency_channels</code>	SEED globing style filter for channels latency monitoring	String
<code>monitoring_period_latency</code>	Period of time in seconds that should be used to find the highest data latency	Integer
<code>monitoring_period_active_channels</code>	Period of time in seconds that should be used to detect number of active channels	Integer
<code>monitoring_period_active_devices</code>	Period of time in seconds that should be used to detect number of active devices	Integer
<code>storage_monitor_dir</code>	Directory that should be used for storage monitoring, if this entry is not present, ringserver's working directory is used.	String

Example file:

```
[Version_1]
filter_monitored_channels="^{1,2}\\..{1,5}\\..N\\..{1,3}"
filter_monitored_latency_channels="^{1,2}\\..{1,5}\\..N\\..{1,3}"
monitoring_period_active_channels=120
monitoring_period_active_devices=300
monitoring_period_latency=30
registry_addresses=127.0.0.1
registry_group_id=guralp3
storage_monitor_dir=/var/cache/guralp/miniseed
```

Data Centre Monitor provides the following functionality:

- It finds the highest latency for channels accepted by the filter and time period configured. The health monitor periodically reads the system log generated by `slinktool` to find the highest channel latency satisfied by the filter and time restrictions. The length of time over which to examine the log file in search of the highest latency is configured in `guralp-monitor.ini` file as `monitoring_period_latency` and is expressed in number of seconds. The channels to be considered for latency search are configured as `filter_monitored_latency_channels` as a SEED globing expression, for example: `DG.?????.0L.???` will select all channels from network `DG` and location `0L` (ie: `DG.12345.0L.HHZ`, `DG.12345.0L.HHN`, `DG.54321.0L.CHZ`).
- It scans for a number of active channels in the time period configured. As for the latency, data centre monitor is periodically examining system log generated by `slinktool` to monitor the number of active channels that pass through the SEED globing filter configured in `filter_monitored_channels` entry of `guralp-monitor.ini` file. System log is scanned for a period as configured in `monitoring_period_active_channels` entry.




- It scans for a number of active devices in the time period configured. Similar to active channels monitoring functionality but does not provide filter configuration. The log file is examined for a period as configured in `monitoring_period_active_devices` entry of `güralp-monitor.ini` file.
- It monitors the state of important services. Health monitor periodically checks the state of services required for the Data Centre to operate correctly. The list of services is configured in `güralp-monitor.ini` file under `monitor_service` entry but it is highly recommended not to modify this configuration entry.
- It sends state of health information to Güralp Responder instances. The service to notify receivers about the latest state of health of the Data Centre sends periodic **UDP** packets on port **11788** to all configured instances of the Güralp Responder servers. The list of servers is configured in `güralp-monitor.ini` file under `registry_addresses` entry. Packets are sent with group identifier configured as `registry_group_id` value.

Güralp responder service

Güralp responder service is a stand-alone application, run as a service, responsible for collection and re-distribution of state of health information packets sent by Güralp seismic stations, Data Centre Monitors, and in special cases, Discovery desktop applications. Responder service is listening on **UDP** port **11788** for incoming state of health packets (device registration), and state of health enquiry (device state of health request).

Communication overview


Data Collection



IRIS ringserver uses `slink2dali` service to collect the data from the seismic station. Data is collected using `SeedLink` protocol through **TCP** connection on port **18000**. Data acquisition for a given station can be started either remotely through Discovery desktop application, or manually by enabling/starting `slink2dali` service for the station when logged into the Data Centre computer, more details on how to start a connection can be found in Güralp Data Centre Operator Manual.




Configuration management



Configuration of Data Centre software package components can be done, under normal operation, by the Discovery desktop application. Discovery provides functionality to configure which seismic stations Data Centre should be connected to and what conditions should be used to generate state of health information. Configuration exchange is performed on port **11788 TCP** connection between Data Centre and Discovery. Discovery requests the current configuration from the Data Centre, modifies it if required, and sends back the updated structure.

Extra configuration may be required during installation and the possible options are described in Güralp Data Centre Installation document.

State of health



State of health information can be distributed to multiple registries by both, Güralp Data Centre Monitor service and Güralp seismic station on port **11788** through **UDP** packets. Information gathered from the system is packetized and sent to configured Güralp Responder servers to be redistributed on request.

State of health information is requested by Discovery desktop application from the registry and displayed in the application main window table. More detailed information about system status can be obtained by accessing either device dashboard (for seismic stations) or state of health dashboard (for data centre instance). More information about how to operate Discovery application can be found in Güralp Data Centre Operator Manual.



Summary

Network protocols and ports

Güralp devices which are using DIG operating system require the following ports to be open/forwarded:


Port	Protocol	Description
80	TCP	HTTP server, required to access device webpage for state of health information and configuration.
1565	TCP	GDI data transmission protocol.
1567	TCP/UDP	GCF data transmission protocol.
4242	TCP	File exchange protocol used by Discovery desktop application to exchange files and configuration.
4244	TCP	Remote console used for debugging, available in Discovery desktop application.
11788	UDP	Remote procedure calls protocol used by the Discovery desktop application to remotely execute functions on the device. This port is also an outgoing port for State of Health packets that are sent to the Güralp Responder server.
18000	TCP	SeedLink data transmission protocol.

Data centre software package requires the following ports to be open:

Port	Protocol	Description
11788	UDP	Used for sending and requesting state of health information by system components and Discovery desktop application.
11788	TCP	Configuration exchange protocol used by Discovery desktop application to configure data streaming connections.
16000	TCP	DataLink data transmission protocol connection to IRIS ringserver.
18000	TCP	SeedLink data transmission protocol connection to IRIS ringserver for both incoming and outgoing data streams.

Appendix 2 - Installation

Software packages diagram





Installation guide

Introduction

This installation guideline provides instructions of how to install Güralp Data Centre acquisition software package with required dependencies. Software package is provided in a form of a set of RPM files that in this document are installed using dnf package manager on Red Hat 8.

Operating system requirements

Güralp Systems Data Centre software package has been tested on the following x86_64 platforms:

- Red Hat Enterprise Linux 8 (or equivalent, e.g. Rocky Linux 8 or AlmaLinux 8)
- Amazon Linux 2

Minimum system dependency requirements are:

- systemd v239
- Qt v5.12.5
- polkit v0.115

Software package content

Software package provided contains 4 RPM files:

- **guralp-datc-0.5-1.el8.x86_64.rpm**
Installs the main components of the Data Centre: IRIS ringserver, Güralp responder and the Data Centre controller and monitor binaries.
- **libmseed-2.19.6-0.1.el8.x86_64.rpm**
Installs libmseed library providing MiniSEED support for SEED related parts of the software solution.
- **slink2dali-0.7b-0.1.el8.x86_64.rpm**
Installs slink2dali executable required to convert SeedLink data received from the seismic station to DataLink data consumed by the IRIS ringserver.
- **slinktool-4.3b-0.1.el8.x86_64.rpm**
Installs slinktool executable required to measure the data latency.

Installation

Software package is provided in a set of RPM files that should be installed using the operating system package manager. This document describes installation procedure on Red Hat Enterprise Linux 8 with dnf package manager.

Installation requires root privileges and access to the RedHat packages repository.

Install libmseed

Install libmseed package from the provided RPM using dnf package manager by executing the following command:

```
sudo dnf install libmseed-2.19.6-0.1.el8.x86_64.rpm
```



Install slinktool

Install slinktool package from the provided RPM using dnf package manager by executing the following command:

```
sudo dnf install slinktool-4.3b-0.1.el8.x86_64.rpm
```

Install slink2dali

Install slink2dali package from the provided RPM using dnf package manager by executing the following command:

```
sudo dnf install slink2dali-0.7b-0.1.el8.x86_64.rpm
```

Install Güralp Data Centre software

Install Güralp Data Centre software package from the provided RPM using dnf package manager by executing the following command:

```
sudo dnf install guralp-datc-0.5-1.el8.x86_64.rpm
```

Verification

Each installation step should complete without failures and all of the required dependencies should be pulled from the package repository. Please contact Güralp support in case of any problems.

Successful installation should result in all of the key services to be enabled and running in the operating system what can be verified by executing the following commands:

- **For Güralp responder:**

```
systemctl status guralp-responder.service
```

Reported status should indicate the service is **active** and **running**.

- **For Güralp Data Centre monitor:**

```
systemctl status guralp-monitor.service
```

Reported status should indicate the service is **active** and **running**.

- **For Güralp Data Centre controller:**



```
systemctl status guralp-controller.service
```

Reported status should indicate the service is **active** and **running**.

- **For IRIS ringserver:**

```
systemctl status iris-ringserver.service
```

Reported status should indicate the service is **active** and **running**.

Additionally, slinktool and slink2dali binaries should be available under /usr/bin directory.

Note: slinktool and slink2dali services are available per seismic station connection therefore installation process will not start those services automatically. In order to create a connection to the remote data server please refer to Güralp Data Centre Operator Manual.

Download

Software packages can be downloaded from Güralp website by following the links below.

Documentation:

- Architecture overview: [docx](#) | [pdf](#)
- Installation guideline: [docx](#) | [pdf](#)
- Operator manual: [docx](#) | [pdf](#)

Software packages:

- Güralp Data Centre package [guralp-datc-0.5-1.platform.x86_64.rpm]:
[Red Hat Enterprise Linux 8](#) | [Amazon Linux 2](#)
- Slink2dali [slink2dali-0.7b-0.1.platform.x86_64.rpm]:
[Red Hat Enterprise Linux 8](#) | [Amazon Linux 2](#)
- Slinktool [slinktool-4.3b-0.1.platform.x86_64.rpm]:
[Red Hat Enterprise Linux 8](#) | [Amazon Linux 2](#)
- MiniSeed library [libmseed-2.19.6-0.1.platform.x86_64.rpm]:
[Red Hat Enterprise Linux 8](#) | [Amazon Linux 2](#)

Support

For support enquiries, please contact support@guralp.com.

Güralp Systems Limited
Midas House, Calleva Park, Aldermaston,
Reading, RG7 8EA,
United Kingdom

Tel: +44 118 981 9056

Fax: +44 118 981 9943

E-mail: sal